1. Heavy Alarm sound and Signal light column for machinery alarm is illuminated NO.2 MAIN AIR COMPRESSOR NO.1 MAIN AIR COMPRESSOR 0 Ö 1.NO.1 LEAD_NO.2 FOLLOW 2.MANUAL 3.NO.2 LEAD_NO.1 FOLLOW 2.Message on ECR computer panel will appear 3. The alarm of the starting air compressor is aknowledged by the operator on the AMS menue. Student will have to press ACKNOWLEDGE BUTTON in ECR computer panel It means just a mute alarm no off all system Fig. 5.: ECR Comp outer panel (Acknowladge button) 4.The alarm horn will and light on signal column will stop blinking but continuously ON

STEPS IN THE APPLICATION OF SCENARIO SCENARIO 11



