## **Steps in the Application of Scenario 4**

1	Avatar of player begins front of the engine room.	
2	Player goes to MOP	2 States Planter Framer High Prosessor
3	Read messages about alarm on MOP screen	EICUXXM_0353-Hydr. Press. too high
4	Press Acknowledge button	ump High Pressure
5	Check CC pressure gauge on MOP	
6	Check CC pressure gauge on panel in engine room	

7 Go to -2 fCCor Go next to CC pumps, they are front 8 of engine Check input and output valves of 9 slave pump (open) 10 Go front of local panel of CC slave pump

11 Start slave pump (If slave pump does

not run)

12 Go front of local panel of CC Master pump




- 13 Stop master pump
- 14 Close input and output valves of master pump



15 Repair the master pump



16 Open input and output valves of master pump



17	Go front of local panel of CC Master pump	
18	Run master pump	
19	Go front of local panel of CC slave pump	
20	Stop slave pump (If slave pump does not run)	
21	Check Alarm Status light on the wall or engine room	
22	Finish	