## **Steps in the Application of Scenario 6**

1	Avatar of player begins front of the engine room.	
2	Player goes to MOP	2 States Planter Framer High Prosessor
3	Read messages about alarm on MOP screen	EICUXXM_0353-Hydr. Press. too high
4	Press Acknowledge button	ump High Pressure
5	Check CC pressure gauge on MOP	
6	Check CC pressure gauge on panel in engine room	

7	Go to -1 floor	
8	Go next to CC filter, they are left the engine	
9	Check input and output valves of slave filter (open)	
10	Go front of local panel of CC slave filter	
11	Close input and output valves of master filter	
12	Clean the master filter	
13	Open input and output valves of master filter	
14	Check Alarm Status light on the wall or engine room	
15	Finish	