












Steps in the Application of Scenario 10

1	Avatar of player begins front of the engine room.	
2	Player goes to ECR alarm computer panel	
3	Read messages about alarm on ECR alarm computer panel	
4	Press Acknowledge button on the keyboard	
5	Stop the main engine by operating STOP button on telegraph	
6	Stop the main LO pump by pressing stop button on main switchboard on LO MASTER pump starter	

7	Stop the main FO pump by pressing stop button on main switchboard on FO MASTER pump starter	
8	Go to the main engine platform in front of Cylinder Head No. 5	
9	Change out exhaust valve at cylinder no 5. by pressing REMOVE / REPAIR /RE-INSTALL	
10	Go back to ECR and START the main LO pump by pressing START button on main switchboard on LO MASTER pump starter	
11	Start the main FO pump by pressing START button on main switchboard on FO MASTER pump starter	
12	Start the main engine by operating START button on telegraph	

13	Finished Scenario	
----	-------------------	--