TROUBLESHOOTING SCENARIOS	
F0RM NO	TR006
SCENARIO NAME	Cooler temputure ise to high
SYSTEM NAME	Centreal Cooling System
Max Time	5 min
SYSTEM DESCRIPTION	The central cooling water system is characterised by having only one heat exchanger cooled by seawater, and by the other coolers, including the jacket water cooler, being cooled by central cool- ing water. In order to prevent too high a scavenge air temperature, the cooling water design temperature in the central cooling water system is normally 36 °C, corresponding to a maximum seawater tem- perature of 32 °C. Our recommendation of keeping the cooling water inlet temperature to the main engine scavenge air cooler as low as possible also applies to the central cooling system. This means that the tem- perature control valve in the central cooling water circuit is to be set to minimum 10 °C, whereby the temperature follows the outboard seawater tem- perature when central cooling water temperature exceeds 10 °C.
Describe the problem	CC Master Filter Clogged PT8401-A: 0.4 Mbar, TI:8101-A:50C
Preparation	<ul> <li>You will hear heavy sound in ER</li> <li>Signal light column for machinery alarm is illuminated</li> <li>Alarm list, COWXX_002, COWXX_003</li> </ul>
SCENARIO ALGORITHM	<ul> <li>1.BEGIN</li> <li>2. Heavy Alarm sound and Signal light column for machinery alarm is illuminate</li> <li>3. Message on ESC MOP-A will appear: <i>alarm messages</i> with red letters</li> <li>4. Student will have to press ACKNOWLEDGE BUTTON in MOP. The alarm horn will SILENT and light on signal column will go OFF,</li> <li>5. The letters on message on ESC MOP-A change color to yellow letters</li> <li>6. Go from Central Cooling Master Filter</li> <li>7. Close inlet and outlet valves of filter</li> <li>8. Remove filter</li> <li>9. Remove filter element and change for clean one</li> <li>10.Re-install new filter element</li> <li>11.Open inlet and outlet valves</li> <li>12.Close redundant filter</li> <li>13.Messages on ESC MOP-A computer panel will DELETE</li> <li>14.END</li> </ul>
QUATIONS	What is CC filter's state? How to respond to dirty cooling filter? What was exact alarm message?
LEARNING OUTCOME	Can maintain the CC system. Can detect the failure of the filter's at CC system. Can change the filter at CC system.